

LAMPIRAN

Coding Pada Arduino Uno R3

```
/*
```

```
Teleduino328EthernetClientProxy.ino - Teleduino328EthernetClientProxy example
```

```
Version 328-0.6.9
```

```
Nathan Kennedy 2009 - 2014
```

```
http://www.teleduino.org
```

```
This sketch is distributed in the hope that it will be useful,  
but WITHOUT ANY WARRANTY; without even the implied warranty of  
MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.
```

```
*/
```

```
#include <EEPROM.h>
```

```
#include <Servo.h>
```

```
#include <Wire.h>
```

```
#include <Teleduino328.h>
```

```
#include <SPI.h>
```

```
#include <Ethernet.h>
```

```
// User configurable variables
```

```
byteuseDhcp = true;
```

```
byteuseDns = true;
```

```
byte mac[] = { 0xDE, 0xAD, 0xBE, 0xEF, 0xFE, 0xED };
```

```
IPAddressdeviceIp(192, 168, 1, 100); // Only if useDhcp is false
```

```
IPAddressgatewayIp(192, 168, 1, 1); // Only if useDhcp is false
```

```
IPAddressdnsIp(192, 168, 1, 1); // Only if useDhcp is false
```

```
IPAddresssubnet(255, 255, 255, 0); // Only if useDhcp is false
```

```
IPAddressserverIp(173, 230, 152, 173); // Only if useDns is false
```

```
charserverName[] = "us01.proxy.teleduino.org"; // Only if useDns is true
```

```
unsignedintserverPort = 5353; // Can be set to either 53 or 5353
```

```
bytestatusLedPin = 8;
```

```

// User configurable key, this is used to authenticate with the proxy server
// This is checked against the EEPROM on boot and written if necessary
// The proxy server retrieves the key from the EEPROM
byte key[] = { 0xC6, 0xBD, 0x91, 0x3B,
               0x56, 0x57, 0xE9, 0x35,
               0x55, 0x41, 0xEE, 0xBE,
               0x8C, 0xC2, 0xA3, 0x90 };

// Other required variables
byte data[257];
byte dataLength;
byte hexStage;
unsigned long lastInstruction = 0;
unsigned long lastRefresh = 0;
byte stage = 0;

// Declare client object
EthernetClient Client;

void setup()
{
    // Load presets
    Teleduino328.loadPresets();

    // Set status LED pin
    Teleduino328.setStatusLedPin(statusLedPin);

    Teleduino328.setStatusLed(1); // Initialisation
    // Check the EEPROM header and check to see if the key is correct
    // This is to ensure the key is not cleared from the EEPROM
    if(EEPROM.read(0) != '#')
    {
        EEPROM.write(0, '#');
    }
}

```

```

if(EEPROM.read(1) != 0)
{
EEPROM.write(1, 0);
}
if(EEPROM.read(2) != '#')
{
EEPROM.write(2, '#');
}
if(EEPROM.read(160) != '#')
{
EEPROM.write(160, '#');
}
for(byte i = 0; i < 16; i++)
{
if(EEPROM.read(161 + i) != key[i])
{
EEPROM.write(161 + i, key[i]);
}
}
if(EEPROM.read(177) != '#')
{
EEPROM.write(177, '#');
}

// Start network and attempt to connect to proxy server
Teleduino328.setStatusLed(2); // Network configuration
if(useDhcp)
{
if(!Ethernet.begin(mac))
Teleduino328.setStatusLed(2, false, 10000);
Teleduino328.reset();
}
}

```

```

else
{
Ethernet.begin(mac, deviceIp, dnsIp, gatewayIp, subnet);
}
delay(1000);

Teleduino328.setStatusLed(3); // Connect to server
if((useDns&& !Client.connect(serverName, serverPort)) || (!useDns&& !Client.connect(serverIp,
serverPort)))
{
Teleduino328.setStatusLed(3, false, 10000);
Teleduino328.reset();
}
lastInstruction = millis();
}

void loop()
{
if(Client.connected())
{
// What we need to do depends on which 'stage' we are at
switch(stage)
{
case 0: // Wait for start byte
if(Client.available())
{
char c = Client.read();
if(c == '?')
{
stage++;
}
}
break;
case 1: // Reset variables

```

```

dataLength = 0;
hexStage = 0;
stage++;
break;
case 2: // Instruction byte
if(Client.available())
    {
char c = Client.read();
if(c == '?')
    {
stage = 1;
break;
    }
else if(c == '\r' || c == '\n' || c == '.')
    {
stage = 0;
break;
    }
if(!hexStage)
    {
data[0] = Teleduino328.hexDecode(c) * 16;
    }
else
    {
data[0] += Teleduino328.hexDecode(c);
    }
hexStage = !hexStage;
if(!hexStage)
    {
stage++;
    }
    }
break;
case 3: // Data length byte

```

```

if(Client.available())
{
char c = Client.read();
if(c == '?')
{
stage = 1;
break;
}
else if(c == '\r' || c == '\n' || c == '.')
{
stage = 0;
break;
}
if(!hexStage)
{
data[1] = Teleduino328.hexDecode(c) * 16;
}
else
{
data[1] += Teleduino328.hexDecode(c);
}
hexStage = !hexStage;
if(!hexStage)
{
stage++;
}
}
break;
case 4: // Data
if(Client.available())
{
char c = Client.read();
if(c == '?')
{

```

```

stage = 1;
break;
    }
else if(c == '\r' || c == '\n' || c == '.')
    {
if(dataLength == data[1])
    {
stage++;
break;
    }
else
    {
stage = 0;
break;
    }
    }
if(!hexStage)
    {
data[2 + dataLength] = Teleduino328.hexDecode(c) * 16;
    }
else
    {
data[2 + dataLength] += Teleduino328.hexDecode(c);
    }
hexStage = !hexStage;
if(!hexStage)
    {
dataLength++;
    }
    }
break;
case 5: // Execute instruction and return result
Teleduino328.instruction(data);
Client.write('!');

```



```

for(int i = 0; i < data[1] + 2; i++)
{
Client.write(Teleduino328.hexEncode(data[i] / 16));
Client.write(Teleduino328.hexEncode(data[i] % 16));
}
Client.write('\n');
lastInstruction = millis();
stage = 0;
break;
}
}
else
{
Teleduino328.setStatusLed(10);
Teleduino328.reset();
}


// Has the instruction timeout been reached?
if(millis() - lastInstruction > 30000)
{
Client.flush();
Client.stop();
Teleduino328.setStatusLed(9);
Teleduino328.reset();
}

// Process refreshes every 50ms
if(millis() - lastRefresh >= 50)
{
Teleduino328.pinTimers();
Teleduino328.shiftRegisterTimers();
Teleduino328.shiftRegisters();
lastRefresh = millis();
}

```

```
// Check to see if reset has been requested  
Teleduino328.checkReset();  
}
```

Arduino UNO



Product Overview

The Arduino Uno is a microcontroller board based on the ATmega328 ([datasheet](#)). It has 14 digital input/output pins (of which 6 can be used as PWM outputs), 6 analog inputs, a 16 MHz crystal oscillator, a USB connection, a power jack, an ICSP header, and a reset button. It contains everything needed to support the microcontroller; simply connect it to a computer with a USB cable or power it with a AC-to-DC adapter or battery to get started. The Uno differs from all preceding boards in that it does not use the FTDI USB-to-serial driver chip. Instead, it features the ATmega8U2 programmed as a USB-to-serial converter.

"Uno" means one in Italian and is named to mark the upcoming release of Arduino 1.0. The Uno and version 1.0 will be the reference versions of Arduino, moving forward. The Uno is the latest in a series of USB Arduino boards, and the reference model for the Arduino platform; for a comparison with previous versions, see the [index of Arduino boards](#).

Index

Technical
Specifications

Page 2

How to use Arduino
Programming Environment, Basic Tutorials

Page 6

Terms &
Conditions

Page 7

Environmental Policies
half sqm of green via Impatto Zero®

Page 7



radiospares

RADIONICS



Technical Specification




EAGLE files: [arduino-duemilanove-uno-design.zip](#) Schematic: [arduino-uno-schematic.pdf](#)

Summary

Microcontroller	ATmega328
Operating Voltage	5V
Input Voltage (recommended)	7-12V
Input Voltage (limits)	6-20V
Digital I/O Pins	14 (of which 6 provide PWM output)
Analog Input Pins	6
DC Current per I/O Pin	40 mA
DC Current for 3.3V Pin	50 mA
Flash Memory	32 KB of which 0.5 KB used by bootloader
SRAM	2KB
EEPROM	1KB
Clock Speed	16MHz

the board



radiospares

RADIONICS



Power

The Arduino Uno can be powered via the USB connection or with an external power supply. The power source is selected automatically.

External (non-USB) power can come either from an AC-to-DC adapter (wall-wart) or battery. The adapter can be connected by plugging a 2.1mm center-positive plug into the board's power jack. Leads from a battery can be inserted in the Gnd and Vin pin headers of the POWER connector.

The board can operate on an external supply of 6 to 20 volts. If supplied with less than 7V, however, the 5V pin may supply less than five volts and the board may be unstable. If using more than 12V, the voltage regulator may overheat and damage the board. The recommended range is 7 to 12 volts.

The power pins are as follows:

- **VIN.** The input voltage to the Arduino board when it's using an external power source (as opposed to 5 volts from the USB connection or other regulated power source). You can supply voltage through this pin, or, if supplying voltage via the power jack, access it through this pin.
- **5V.** The regulated power supply used to power the microcontroller and other components on the board. This can come either from VIN via an on-board regulator, or be supplied by USB or another regulated 5V supply.
- **3V3.** A 3.3 volt supply generated by the on-board regulator. Maximum current draw is 50mA.
- **GND.** Ground pins.

Memory

The Atmega328 has 32 KB of flash memory for storing code (of which 0,5 KB is used for the bootloader); It has also 2 KB of SRAM and 1 KB of EEPROM (which can be read and written with the [EEPROM library](#)).

Input and Output

Each of the 14 digital pins on the Uno can be used as an input or output, using [pinMode\(\)](#), [digitalWrite\(\)](#), and [digitalRead\(\)](#) functions. They operate at 5 volts. Each pin can provide or receive a maximum of 40 mA and has an internal pull-up resistor (disconnected by default) of 20-50 kOhms. In addition, some pins have specialized functions:

- **Serial: 0 (RX) and 1 (TX).** Used to receive (RX) and transmit (TX) TTL serial data. These pins are connected to the corresponding pins of the ATmega8U2 USB-to-TTL Serial chip.
- **External Interrupts: 2 and 3.** These pins can be configured to trigger an interrupt on a low value, a rising or falling edge, or a change in value. See the [attachInterrupt\(\)](#) function for details.
- **PWM: 3, 5, 6, 9, 10, and 11.** Provide 8-bit PWM output with the [analogWrite\(\)](#) function.
- **SPI: 10 (SS), 11 (MOSI), 12 (MISO), 13 (SCK).** These pins support SPI communication, which, although provided by the underlying hardware, is not currently included in the Arduino language.
- **LED: 13.** There is a built-in LED connected to digital pin 13. When the pin is HIGH value, the LED is on, when the pin is LOW, it's off.



radiospares

RADIONICS



The Uno has 6 analog inputs, each of which provide 10 bits of resolution (i.e. 1024 different values). By default they measure from ground to 5 volts, though it is possible to change the upper end of their range using the AREF pin and the [analogReference\(\)](#) function. Additionally, some pins have specialized functionality:

- **I²C: 4 (SDA) and 5 (SCL).** Support I²C (TWI) communication using the [Wirelibrary](#).

There are a couple of other pins on the board:

- **AREF.** Reference voltage for the analog inputs. Used with [analogReference\(\)](#).
- **Reset.** Bring this line LOW to reset the microcontroller. Typically used to add a reset button to shields which block the one on the board.

See also the [mapping between Arduino pins and Atmega328 ports](#).

Communication

The Arduino Uno has a number of facilities for communicating with a computer, another Arduino, or other microcontrollers. The ATmega328 provides UART TTL (5V) serial communication, which is available on digital pins 0 (RX) and 1 (TX). An ATmega8U2 on the board channels this serial communication over USB and appears as a virtual com port to software on the computer. The '8U2 firmware uses the standard USB COM drivers, and no external driver is needed. However, on Windows, an *.inf file is required..

The Arduino software includes a serial monitor which allows simple textual data to be sent to and from the Arduino board. The RX and TX LEDs on the board will flash when data is being transmitted via the USB-to-serial chip and USB connection to the computer (but not for serial communication on pins 0 and 1).

A [SoftwareSerial library](#) allows for serial communication on any of the Uno's digital pins.

The ATmega328 also support I2C (TWI) and SPI communication. The Arduino software includes a Wire library to simplify use of the I2C bus; see the [documentation](#) for details. To use the SPI communication, please see the ATmega328 datasheet.

Programming

The Arduino Uno can be programmed with the Arduino software ([download](#)). Select "Arduino Uno w/ ATmega328" from the **Tools > Board** menu (according to the microcontroller on your board). For details, see the [reference](#) and [tutorials](#).

The ATmega328 on the Arduino Uno comes preburned with a [bootloader](#) that allows you to upload new code to it without the use of an external hardware programmer. It communicates using the original STK500 protocol ([reference](#), [C header files](#)).

You can also bypass the bootloader and program the microcontroller through the ICSP (In-Circuit Serial Programming) header; see [these instructions](#) for details.

The ATmega8U2 firmware source code is available . The ATmega8U2 is loaded with a DFU bootloader, which can be activated by connecting the solder jumper on the back of the board (near the map of Italy) and then resetting the 8U2. You can then use [Atmel's FLIP software](#) (Windows) or the [DFU programmer](#) (Mac OS X and Linux) to load a new firmware. Or you can use the ISP header with an external programmer (overwriting the DFU bootloader).



Automatic (Software) Reset

Rather than requiring a physical press of the reset button before an upload, the Arduino Uno is designed in a way that allows it to be reset by software running on a connected computer. One of the hardware flow control lines (DTR) of the ATmega8U2 is connected to the reset line of the ATmega328 via a 100 nanofarad capacitor. When this line is asserted (taken low), the reset line drops long enough to reset the chip. The Arduino software uses this capability to allow you to upload code by simply pressing the upload button in the Arduino environment. This means that the bootloader can have a shorter timeout, as the lowering of DTR can be well-coordinated with the start of the upload.

This setup has other implications. When the Uno is connected to either a computer running Mac OS X or Linux, it resets each time a connection is made to it from software (via USB). For the following half-second or so, the bootloader is running on the Uno. While it is programmed to ignore malformed data (i.e. anything besides an upload of new code), it will intercept the first few bytes of data sent to the board after a connection is opened. If a sketch running on the board receives one-time configuration or other data when it first starts, make sure that the software with which it communicates waits a second after opening the connection and before sending this data.


The Uno contains a trace that can be cut to disable the auto-reset. The pads on either side of the trace can be soldered together to re-enable it. It's labeled "RESET-EN". You may also be able to disable the auto-reset by connecting a 110 ohm resistor from 5V to the reset line; see [this forum thread](#) for details.

USB Overcurrent Protection

The Arduino Uno has a resettable polyfuse that protects your computer's USB ports from shorts and overcurrent. Although most computers provide their own internal protection, the fuse provides an extra layer of protection. If more than 500mA is applied to the USB port, the fuse will automatically break the connection until the short or overload is removed.

Physical Characteristics

The maximum length and width of the Uno PCB are 2.7 and 2.1 inches respectively, with the USB connector and power jack extending beyond the former dimension. Three screw holes allow the board to be attached to a surface or case. Note that the distance between digital pins 7 and 8 is 160 mil (0.16"), not an even multiple of the 100 mil spacing of the other pins.



radiospares

RADIONICS



How to use Arduino



Arduino can sense the environment by receiving input from a variety of sensors and can affect its surroundings by controlling lights, motors, and other actuators. The microcontroller on the board is programmed using the [Arduino programming language](#) (based on [Wiring](#)) and the Arduino development environment (based on [Processing](#)). Arduino projects can be stand-alone or they can communicate with software on running on a computer (e.g. Flash, Processing, MaxMSP).

Arduino is a cross-platform program. You'll have to follow different instructions for your personal OS. Check on the [Arduino site](http://arduino.cc/en/Guide/HomePage) for the latest instructions. <http://arduino.cc/en/Guide/HomePage>

Linux Install

Windows Install

Mac Install

Once you have downloaded/unzipped the arduino IDE, you can Plug the Arduino to your PC via USB cable.

Blink led

Now you're actually ready to "burn" your first program on the arduino board. To select "blink led", the physical translation of the well known programming "hello world", select

File>Sketchbook> Arduino-0017>Examples> Digital>Blink

Once you have your sketch you'll see something very close to the screenshot on the right.

In **Tools>Board** select

Now you have to go to

Tools>SerialPort and select the right serial port, the one arduino is attached to.



Done compiling.

Press Compile button
(to check for errors)



Upload



TX RX Flashing



Blinking Led!





radiospares

RADIONICS



Dimensioned Drawing



Terms & Conditions



1. Warranties

1.1 The producer warrants that its products will conform to the Specifications. This warranty lasts for one (1) years from the date of the sale. The producer shall not be liable for any defects that are caused by neglect, misuse or mistreatment by the Customer, including improper installation or testing, or for any products that have been altered or modified in any way by a Customer. Moreover, The producer shall not be liable for any defects that result from Customer's design, specifications or instructions for such products. Testing and other quality control techniques are used to the extent the producer deems necessary.

1.2 If any products fail to conform to the warranty set forth above, the producer's sole liability shall be to replace such products. The producer's liability shall be limited to products that are determined by the producer not to conform to such warranty. If the producer elects to replace such products, the producer shall have a reasonable time to replacements. Replaced products shall be warranted for a new full warranty period.

1.3 EXCEPT AS SET FORTH ABOVE, PRODUCTS ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." THE PRODUCER DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING PRODUCTS, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE

1.4 Customer agrees that prior to using any system that includes the producer products, Customer will test such systems and the functionality of the products as used in such systems. The producer may provide technical, applications or design advice, quality characterization, reliability data or other services. Customer acknowledges and agrees that providing these services shall not expand or otherwise alter the producer's warranties, as set forth above, and no additional obligations or liabilities shall arise from the producer providing such services.

1.5 The Arduino™ products are not authorized for use in safety-critical applications where a failure of the product would reasonably be expected to cause severe personal injury or death. Safety-Critical Applications include, without limitation, life support devices and systems, equipment or systems for the operation of nuclear facilities and weapons systems. Arduino™ products are neither designed nor intended for use in military or aerospace applications or environments and for automotive applications or environment. Customer acknowledges and agrees that any such use of Arduino™ products which is solely at the Customer's risk, and that Customer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

1.6 Customer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products and any use of Arduino™ products in Customer's applications, notwithstanding any applications-related information or support that may be provided by the producer.

2. Indemnification

The Customer acknowledges and agrees to defend, indemnify and hold harmless the producer from and against any and all third-party losses, damages, liabilities and expenses it incurs to the extent directly caused by: (i) an actual breach by a Customer of the representation and warranties made under this terms and conditions or (ii) the gross negligence or willful misconduct by the Customer.

3. Consequential Damages Waiver

In no event the producer shall be liable to the Customer or any third parties for any special, collateral, indirect, punitive, incidental, consequential or exemplary damages in connection with or arising out of the products provided hereunder, regardless of whether the producer has been advised of the possibility of such damages. This section will survive the termination of the warranty period.

4. Changes to specifications

The producer may make changes to specifications and product descriptions at any time, without notice. The Customer must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." The producer reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them. The product information on the Web Site or Materials is subject to change without notice. Do not finalize a design with this information.



Environmental Policies




The producer of Arduino™ has joined the Impatto Zero® policy of LifeGate.it. For each Arduino board produced is created / looked after half squared Km of Costa Rica's forest's.


radiospares
RADIONICS


"Arduino" name and logo are trademarks registered by Arduino S.r.l. in Italy, in the European Union and in other countries of the world.

Arduino[®] UNO



Author: G.Martino
arduino_Uno_Rev3e
23.01.2015 09:38:56
Sheet: 1/1

W5100 Ethernet Shield

-A high performance Ethernet shield for Arduino

Overview



W5100 Ethernet shield is a WIZnet W5100 breakout board with POE and Micro-SD designed for Arduino platform. 5V/3.3V compatible operation voltage level makes it compatible with Arduino boards, leafmaple, and other Arduino compatible board.

Features

- With Micro SD interface
- 5V/3.3V double operational voltage level
- 10Mb/100Mb Ethernet socket with POE
- All electronic brick interface are broken out
- Operation temperature: -40°C ~+85°C

Specifications

PCB size	55.88mm X 68.58mm X 1.6mm
Indicators	TX,RX,COL,FEX,SPD,LNK
Power supply	5V
Communication Protocol	SPI
RoHS	Yes

Electrical Characteristics

Specification	Min	Type	Max	Unit
Power Voltage	3V	-	5.5	VDC
Input Voltage VH:	3	-	5.5	V
Input Voltage VL:	-0.3	0	0.5	V
Current	-	-	100	mA

Hardware




Figure 1 Top Map

Arduino PIN	Description
D0	Rx/Breakout
D1	TX/Breakout
D2	Breakout
D3	Breakout
D4	SD_CS
D5	Breakout
D6	Breakout
D7	Breakout
D8	Breakout
D9	W5100_Reset
D10	W5100_CS
D11	MOSI
D12	MISO
D13	SCK

A0	Breakout
A1	Breakout
A2	Breakout
A3	Breakout
A4	IIC_SDA/Breakout
A5	IIC_SCL/Breakout

Installation

When install W5100 Ethernet shield to Iteaduno, please check the operation voltage level of development board. If the voltage is 3.3V (IFLAT32,Leafmaple), set the Operation Level Setting switch to 3.3V. If the voltage is 5V (Arduino), set the Operation Level Setting switch to 5V.

Iteaduno communicates with both the W5100 and SD card using the SPI bus. This is on digital pins 11, 12, and 13 on the UNO/Duemilanove and pins 50, 51, and 52 on the Mega. On both boards, pin 10 is used to select the W5100 and pin 4 for the SD card. These pins cannot be used for general I/O. On the Mega, the hardware SS pin, 53, is not used to select either the W5100 or the SD card, but it must be kept as an output. Note that because the W5100 and SD card share the SPI bus, only one can be active at a time. If you are using both peripherals in your program, this should be taken care of by the corresponding libraries. If you're not using one of the peripherals in your program, however, you'll need to explicitly deselect it. To do this with the SD card, set pin 4 as an output and write a high to it. For the W5100, set digital pin 10 as a high output.

Indicator LED


The shield contains a number of informational LEDs:

- LNK: indicates the presence of a network link and flashes when the shield transmits or receives data
- FEX: indicates that the network connection is full duplex

- SPD: indicates the presence of a 100 Mb/s network connection (as opposed to 10Mb/s)
- RX: flashes when the shield receives data
- TX: flashes when the shield sends data
- COL: flashes when network collisions are detected

Revision History

Rev.	Description	Release date
v1.0	Initial version	2012-09-14



B

C

D

Title		Revision	
Size	Number		
A4			
Date:	2012-2-28	Sheet of	
File:	D:_L\	SchDoc	
		Drawn By:	

